ポータブルミニディスクプレーヤー

取扱説明書/Operating Instructions

お買い上げいただきありがとうございます。

電気製品は安全のための注意事項を守らないと、 火災や人身事故になることがあります。

この取扱説明書には、事故を防ぐための重要な注意事項と製品の取り扱いかたを示しています。 この取扱説明書と別冊の「安全のために」をよくお読みのうえ、製品を安全にお使いください。 お読みになったあとは、いつでも見られるところに必ず保管してください。

MZ-E7W



3-044-845-**11**(1)

主な特長

本機はソニーが開発したミニディスクフォーマットを採用したポータブルミニディス

- 腕時計型のワイヤレスコントローラーで操作できるミニディスクプレーヤー 本体プレーヤー部の基本操作ができ、バックライト付きのディスプレイに、曲名や 再生状況を9文字ワイド表示します。
- ディスクの出し入れが快適な「ワンタッチイジェクト」機能
- 側面のボタンを押すだけでふたが開き、ディスクが出てきます。
- 充実した腕時計機能
- カレンダー・ストップウォッチ・アラームなどの腕時計としての基本機能を装備し ました。
- 電池持続時間の長時間化を実現した省電力設計
- ・ 約40秒の音飛びガードメモリー搭載

MD WALKMANは、ソニー株式会社の商標です。

保証書とアフターサービス

- この製品には保証書が添付されていますので、お買い上げの際お買い上げ店でお受け
- 所定事項の記入および記載内容をお確かめのうえ、大切に保存してください。 ・ 保証期間は、お買い上げ日より1年間です。
- アフターサービス
- 調子が悪いときはまずチェックを
- この説明書をもう一度ご覧になってお調べください。
- それでも具合の悪いときはサービスへ
- 添付の「テクニカルインフォメーションセンターのご案内」にあるお近くのソニーサー ビス窓口にご相談ください。 保証期間中の修理は

保証書の記載内容に基づいて修理させていただきます。詳しくは保証書をご覧くださ • 保証期間経過後の修理は

修理によって機能が維持できる場合は、ご要望により有料修理させていただきます。

当社ではポータブルミニディスクプレーヤーの補修用性能部品(製品の機能を維持す るために必要な部品)を、製造打ち切り後最低8年間保有しています。この部品保有期 間を修理可能の期間とさせていただきます。保有期間が経過した後も、故障箇所によ っては修理可能の場合がありますので、お買い上げ店か、サービス窓口にご相談くだ

ソニーではMZ-E7Wのお客様技術相談窓口として「テクニカルインフォメーションセンター」を 開設しています。

お使いになって不明な点や技術的な相談は下記までお問い合わせください。 テクニカルインフォメーションセンター

電話: 048-794-5194

受付時間: 月~金 午前9時から午後5時まで(祝日、年末、年始、弊社休日を除く) 受付期間: お買い上げ日より1年間

ご相談になるときは次のことをお知らせください

- 型名:MZ-E7W
- 故障の状態:できるだけ詳しく
- お買い上げ年月日

アフターサービスを依頼するときは

ソニー株式会社 〒141-0001 東京都品川区北品川6-7-35

必ず本体とヘッドホン、ワイヤレスコントローラーのすべてをお持ちください。

準備する。

電源は、付属の充電式電池や別売りの乾電池を本体に、付属のボタン型電池をワイ ヤレスコントローラーに使います。くわしくは、「電源について」をご覧ください。

充電式電池(本体用)を充電する

約1.5時間で充電ランプが消え、充電が完了します。(充電完了後ランプが消えた 状態で、さらに約1時間充電し続けてからお使いになると、電池の特性を最大限 に生かすことができます。)




本体に充電式電池を入れる





ワイヤレスコントローラーに電池を入れる

裏面の電池のふたをコイン






+ と書かれた面を上にして、

ワイヤレス機能を働かせる

お買い上げ時の設定のままで、ワイヤレスコントローラーを使って本機を操作す ることができます。(お買い上げ時のチャンネル設定は「A(ch)」になっています。)



- ① 本体のWIRELESS CONTROLスイッチが「ON」になっていることを確認する。 飛行機内で本体のみを操作してご使用になる場合以外、通常ご使用時には、「OFF」 にする必要はありません
- ② 本体のCH切換えスイッチが「A」になっていることを確認する。 他のワイヤレスコントローラーと電波が混信する場合は、③~⑥にしたがって、チ ャンネル(CH)を切り換えてください。(以下は「A(ch)」から「B(ch)」に切り換える
- ③ ボールペンなど先のとがったもので、本体のCH切換えスイッチを「B」にする。
- 4 ワイヤレスコントローラーのMODEをくり返し押してモード表示にし、モード表示 の間にワイヤレスコントローラーのMODEを約3秒間押したままにする。 チャンネル表示




6 ワイヤレスコントローラーの操作つまみを右にずらして、決定する。

① OPENボタンを押します。

② ミニディスクを入れ、ふたを閉めます。



本体裏面



- しっかり差し込みます。
- ② ▶▶ ▶ を押す。(ワイヤレスコントローラーでは操作つまみを右にずらす。) 本体のOPERATEランプが点灯し、ディスクの最初から再生が始まります。 ワイヤレスコントローラーで操作すると「ピ」と確認音がします。
- ワイヤレスコントローラーをご使用のときは、表示窓で音量を確認できます。

本体のOPERATEランプが消えます。 ワイヤレスコントローラーで操作すると「ピー」と確認音がします。

ワイヤレスコントローラーについて 本体とワイヤレスコントローラーの間では電波を使って、次のようなやりとりをしています。

本体が受信すると、本体の通信ランプが点灯します。 诵信表示には次の2種類があります。

操作表示 (T))



や頭出し、音量調節などの操作をす

リピート再生や曲名表示を選ぶ

電波でやりとりしていますので、ご使用の際には次のことにご注意ください。

用しないでください。 必ず本体のWIRELESS CONTROLスイッチを「OFF」にしてください。 MDを聞く場合は、本体のみで操作してお使いください。(ただし、離着陸時など電子機器の


— ワイヤレスコントローラー、または本体の近くに電波の障害になる物がある。


付属のワイヤレスコントローラーは本機専用です。

ミニディスクを聞くB

再生するときには、音源に合わせて自動的にステレオまたはモノラルに音声が切り

ミニディスクを入れる






- ① ヘッドホン(付属)を○ジャックへつなぐ。
- ③ VOLUME + / で音量を調節する。

止めるには、■(ワイヤレスコントローラーでは操作つまみ)を押す。

— ワイヤレスコントローラーから本体へ操作指示を送る 本体からワイヤレスコントローラーへ情報を送る ワイヤレスコントローラーと本体の間で通信が行われているときは、表示窓に通信表示が出ます。



ワイヤレスコントローラーで、再生

・ 飛行機内では、通信電波などを乱すおそれがありますので、ワイヤレスコントローラーは使

使用が制限されている場合は使用しないでください。 • 本体とワイヤレスコントローラーは約1m以内の距離でお使いください。

- 次のような場合、受信状態が悪くなったり、操作距離が短くなることがあります。 ― ヘッドホンのコードを本体に巻きつけて使用している。 — 近くに金属物がある。または金属ラベルのMDを使用している
- ― コンピューター、ワープロ周辺など電気ノイズの大きい所で使用している。
- テレビ塔、ラジオ塔の近くなど電波の強い所で使用している。 - 車内、電車内で使用している。
- ラジオやワイヤレスウォークマンを聞いている人の近くで使用している。 受信状態が悪いとき、または操作できないときは、本体およびワイヤレスコントローラーの向きや 位置または持ちかたを変えてみてください。

本体裏面

にずらす(ピピピ) 前の曲を頭出しする **▶** を2回押す ラーでは操作つまみを左 に2回ずらす(ピピピ・ 次の曲を頭出しする ▶▶ を押す

᠀ぁ ワイヤレスコントロー

にずらしたままにする

- では操作つまみを右

操作(ワイヤレスコント

ワイヤレスコントロー

ローラーの確認音)

ラーでは操作つまみを右 ワイヤレスコントロー にずらしたままにする 再生しながら早送り ▶▶ ▶ を押したままに

こんなときは

今聞いている曲を頭 ► ◆ を押す

ディスクを取り出す ■(ワイヤレスコントロー ラーでは操作つまみ)を押 してから、本体のOPFN ボタンを押す*

再生を始められないときは ホールド(誤操作防止状態)になっていませ んか。くわしくは、「誤操作を防ぐ(ホール ド機能)」をご覧ください。

ワイヤレスコントローラーで操作 できないときは

ワイヤレスコントローラーで操作をしたと きに、表示窓に表示される右側のアンテナ マークが下に隠れてしまった場合は、ワイ ヤレスコントローラーと本体の間できちん と通信が行われていません。



このようなときは、 • ワイヤレスコントローラーの位置や向き

を変えて、もう一度同じ操作をしてくだ • ワイヤレス機能が正しく設定されていな

い可能性があります。「準備する の 手順4「ワイヤレス機能を働かせる」にし たがって、確認してください。

表示窓の見かた くわしくは、「曲名や曲の時間を見る」をご 覧ください。



ちょっと一言 • 再生中は本体のOPERATEランプが点灯しま す。OPERATEランプは■(ワイヤレスコント

ローラーでは操作つまみ)を押すと消えます。 ワイヤレスコントローラーの表示は、操作を てから一定時間後に時計表示に変わります。

再生中にOPENボタンを押さないでください。 ふたが開き、ディスクの再生が中断されてしまい ます。

別売りのリモートコントローラーを使う場

本機は、MDウォークマン用リモートコントロー ラー(RM-MZE1など)をOジャックにつないで使 用することができます。(ただし、別売のリモート コントローラーをつないでいるときは、付属のワ イヤレスコントローラーで本体を操作できませ ん。操作についてくわしくは、リモートコントロ

*1)ふたを開けると、次の再生はディスクの最初 から始まります。 *2)曲名やディスク名などの文字情報を記録して

いるディスクのときのみ表示します。

ーラーの取扱説明書をご覧ください。

▶いろいろな聞きかた

DIGITAL MEGABASS F AVLS G ワイヤレスコントローラー

-VOLUME + C

-VOLUME - **D**

決定:右にずらす

一操作つまみ

くりかえし聞く (リピート再生)

MODEをくり返し押して、モード

(T J3

03:12

2 再生表示の間にワイヤレスコント

ローラーのVOLUME + を押す。

押すたびに次のように変わります。

再生状態表示 SHUF

ディスク全曲を1回再生します。←

ディスク全曲をくりかえし再生します。

今、再生している曲をくりかえし再生します。

全曲を順不同に並びかえて再生し、さらに

表示なし(通常の再生)

(全曲リピート)

〜 1(1曲リピート)

SHUF

(シャッフルリピート)

くりかえし並びかえて再生します。

便利な機能を使う

モード表示を選ぶ。

本体が受信すると

表示が切り換わる。

モード表示

再生表示

再生中に曲名やディスク名、曲番、曲の経過

時間、録音されている曲数を確認できます。

ラーのMODEをくり返し押して、

T JJ

03:12

1 再生中にワイヤレスコントロー

003

表示を選ぶ

本体が受信すると

表示が切り換わる。 ▼

モード表示

再生表示

あります。

MODE -

ディスク全曲のリピート、1曲のリピー 誤操作を防ぐ(ホールド機能) [1] 、シャッフルリピートの3通りの方法が カバンに入れて使うときなど、誤ってボタ ンが押された場合、動作してしまうことを **1** ワイヤレスコントローラーの 防ぎます。

> HOLDスイッチをずらす。 本体のHOLDスイッチを──の方向にずら すと本体の操作ボタンが、働かなくなりま

曲名やディスク名などの文字情報を記録してい

ないディスクでは、文字情報は表示されません。

ディスクに

2 再生表示の間にワイヤレスコント

ローラーのVOLUME - を押す。

押すたびに表示は次のように変わりま

低音を強調する (デジタルメガベース)匠 低音域が強調された迫力のある再生が楽し めます。

DIGITAL MEGABASSスイッチを「1」 またば2」にする。 「1(弱)と「2(強)の2段階のメガベース効

DIGITAL MEGABASS

果が働きます。 メガベースを使っているときに音量を上げすぎ ると、音がわれたり、ひずんだりすることがあり ます。その場合は音量を下げてください。

音もれを抑える (音量リミット AVLS)**G** 音量の上げすぎによる音もれや、耳への圧 迫感、周囲の音が聞こえないことでの危険 を少なくし、より快適な音量で聞くことが できます。 AVLSスイッチを「LIMIT」にする。

くなりません。



▶時計機能について

時計/カレンダーを合 わせる

時計 / カレンダーを合わせることによっ て、ワイヤレスコントローラーを腕時計と して使うことができます。

1 ワイヤレスコントローラーの MODEをくり返し押して、時計表 示を選ぶ。 時計表示



ローラーのMODEを約3秒間押し

たままにする。 カレンダー設定表示になり、「年(西 暦の下2桁表示が点滅します。 カレンダー 設定表示 ('00√ 1/

3 ワイヤレスコントローラーの VOLUME + / - をくり返し押し て、「年」を合わせる。

4 ワイヤレスコントローラーの操作 つまみを右にずらして、「年」を決 定する。 「月」が点滅します。 手順3、4と同じようにして、「月」

前の項目を合わせ直すには、ワイヤレ

「日」を合わせます。 MODEを約3秒間押したままにす 「日」が点滅しているときに、ワイヤレ スコントローラーの操作つまみを右に ずらすと「日」が決定し、時計設定表示 になります。

スコントローラーの操作つまみを左に ずらします。 5 時計の12時間表示か24時間表示 定する。

を選ぶ。 「分」が点滅します。 ワイヤレスコントローラーの VOLUME + / - を押して「12H」または 「24H」を選び、操作つまみを右にずら して決定します。 ら、手順3からやり直します。

時計設定表示 0:00

6 手順3、4と同じようにして、 「時」「分」を合わせる。 「分」が点滅しているときに、ワイヤレ スコントローラーの操作つまみを右に ずらすと、秒の設定が「00」になり、設 音量を調節しても、一定のレベル以上大き 定した時刻で時計が動き始めます。

> 途中で止めるには ワイヤレスコントローラーのMODEを押します。

時間を計測する■

(ストップウォッチ機能)

ワイヤレスコントローラーをストップウォ ッチとして使うことができます。 また、時間の計測中に、途中までの経過時 間を見ることもできます(スプリットタイ

1 ワイヤレスコントローラーの MODEをくり返し押して、ストッ プウォッチ表示を選ぶ。 ストップウォッチ

00:00:00

2 ワイヤレスコントローラーの VOLUME - を押す。 カウントが始まります。 もう一度ワイヤレスコントローラーの VOLUME - を押すと、カウントが停 止します。

カウントをリセットするには カウント停止中にワイヤレスコントローラーの VOLUME + を押します。

スプリットタイムを計測するには カウントしているときにワイヤレスコントロー ラーのVOLUME + を押します。 (スプリットタイム(SP)表示が出ます。) もう一度押すと、スプリットタイム表示が消え、 ストップウォッチ(SW)表示に戻ります。 (カウントは継続しています。)

アラームを鳴らすり

アラームを3つまで設定することができます。 アラームを設定する前に、必ず時計の設定をし てください。



2 ワイヤレスコントローラーの VOLUME - をくり返し押して、 AL1~3の中から選ぶ。 **3** ワイヤレスコントローラーの

「時」が点滅します。 **4** ワイヤレスコントローラーの

て、「時」を合わせる。 **5** ワイヤレスコントローラーの操作 つまみを右にずらして、「時」を決

> 「時」を合わせ直すには、ワイヤレスコ ントローラーのMODEを押して、アラ ームの時刻設定をいったん止めてか

VOLUME + / - をくり返し押し

6 手順4、5と同じようにして、「分」 を合わせる。 ワイヤレスコントローラーの操作つま みを右にずらすと、設定が登録され、

((*)が表示されます。) 途中で止めるには ワイヤレスコントローラーのMODEを押します。 アラーム機能を解除するには

VOLUMF + を押します

アラームを止めるには

きません。

アラーム機能が働きます。

((*)の表示が消えます。) アラーム機能を再び働かせるには アラーム表示のときに、働かせたいアラーム設定 (AL1~3)を選び、ワイヤレスコントローラーの VOLUME + を押します。 ((*)が表示されます。)

アラーム表示のときに、解除したいアラーム設定

(Al 1~3)を選び、ワイヤレスコントローラーの

ワイヤレスコントローラーの操作つまみなどの いずれかを押します。 時計が設定されていないと、アラームの設定はて

バックライトを点灯さ


押している間と指を離してから約5秒間バ ックライトが点灯します。

▶電源について


アルカリ乾電池で使う

ワイヤレスコントローラーのLIGHTを

1 付属の乾電池ケースに単3型アル カリ乾電池 別売り を入れる。 ふたを閉めるときは、ふたと本体のマ - クを合わせるように回して、確実に 閉めてください。



2 乾電池ケースを取り付ける。



LOCK側に回します。 (取りはずすときは、 充電式電池・乾電池およびリチウム電池の取り

本体:本体とワイヤレスコントローラーの間で通 信が行われているときに、表示窓に「LOW BATT 表示が点滅し、しばらくすると電源が切れます。 ワイヤレスコントローラー:ワイヤレスコントロ ーラーが時計表示のときに、「秒」表示が点滅し、電 池の交換時期であることをお知らせします。 また、「秒」表示が点滅しなくても、本体とワイヤレ スコントローラーの通信距離が極端に短くなった り、まったく通信できなくなった場合も電池の交

換え時期は

換時期になります。 充電式電池・乾電池およびリチウム電池の持続

使用電池 使用時間 充電式ニッケル水素電池 約15時間*2 ソニーアルカリ乾電池 LR6 (SG) 1本

ニッケル水麦雷池 (NH-14WM)の併用 ワイヤレスコントローラー

ソニーアルカリ乾電池 LR6 (SG) 1本と充電式

*2)100%充電したときの時間です。

使用電池 使用時間

約40時間*2

リチウム電池CR2032 約3ヶ月*3 *1)周囲の温度や使用状態により、上記の持続時 間と異なる場合があります。

*3)1日約60回の操作を毎日行った場合

分解しないでください ミニディスクプレーヤーに使われているレ ーザー光が目にあたると危険です。

レンズに触れないでください レンズが汚れると音飛びが起きたり、再生 できなくなったりする場合があります。 また、ほこりがつかないように、ディスク の出し入れ以外はふたを必ず閉じておいて ください。

充電式電池について

- 充電には必ず付属の充電器をお使いくだ さい。 • 充電時間は充電式電池の使用状態により
- 異なります。
- はじめて充電するときや、長時間使用し なかったあとでは、充電しても通常の使 用時間より短いことがあります。何回か 放電、充電をくりかえすと通常の状態に 戻ります。
- 充電式電池を充分に充電しても使える時 間が通常の半分くらいになったときは、 新しい充電式電池と取り換えてくださ
- 充電式電池を持ち運ぶときは付属のバッ テリーキャリングケースに入れてくださ い。ケースに入れずに、キーホルダーな どの金属類と一緒にポケットやバッグな どに入れると、電池の+と-がショート して危険です。
- 長い間使用しないときは、充電式電池を 本体から取り出しておいてください。



ニッケル水素電池は、リサ イクルできます。不要にな ったニッケル水素電池は 金属部にセロハンテープな _ どの絶縁テープを貼って充 Ni-MH 電式電池リサイクル協力店 へお持ちください。

充電式電池の収集・リサイクルおよびリサ イクル協力店に関する問い合わせ先 **社団法人雷池丁業会**

TEL: 03-3434-0261 ホームページ: http://www.bai.or.ip

本体の乾電池ケース取り付け部に ついて

本体に充電式電池が入ったままの状態で、 取り付け部の端子に金属などがふれると、 ショートし、発熱することがあり危険で

バッグなどに入れて持ち運ぶときは、付属 のキャリングポーチに入れてください。

乾電池・乾電池ケースについて • 乾電池の使いかたを誤ると、液もれや破 裂のおそれがあります。次のことを必ず

- お守りください。 — +と - の向きを正しく入れてくださ
- 乾電池は充電できません。 ― 長い間使わないときは、取り出して
- おいてください。 • 液もれが起こったときは、液をよくふき
- とってから新しい電池を入れてくださ
- 持ち運ぶときはキーホルダーなどの金属 類と一緒にポケットやバッグなどに入れ ないでください。電池の+と-の端子、 または乾電池ケースの端子に金属がふれ るとショートし、発熱することがあり危 険です。

乾電池ケースのふたに関するご注意 本機に付属している乾電池ケースのふた は、無理な力が加わったときにはずれるよ うになっています。このような場合、以下 の手順でふたを本体にはめ込んで下さい。 もとどおりご使用になれます。



① 乾電池ケースのミゾ部に、ふたの軸部 を合わせる。



② ふたを図のようにして、上図の①、② の手順で軸部を片側ずつミゾ部へはめ 込む。

ボタン型電池誤飲防止について • ワイヤレスコントローラーの電源にはボ

タン型電池を使用しています。

• ボタン型電池を誤って飲み込むことのな いよう、ワイヤレスコントローラーおよ び電池は特に幼児の手の届かないところ に置いてください。

• 時計本体およびバンドは、直接肌に接触

• 万一電池を飲み込んだ場合には、直ちに 医師と相談してください。

かぶれについて

- しているため、使用状態によってはかぶ れを起こすおそれがあります。 かぶれの原因として、①金属・プラスチ ックに対するアレルギー、②時計本体お よびバンドの汚れ・サビ・汗など、③体 調不良などが考えられます。
- バンドは余裕を持たせてご使用くださ
- 万一異常が生じた場合は、ご使用を中止 し、医師にご相談ください。

置き場所について

- 次のような場所には置かないでください。 • 直射日光の当たる場所や暖房器具の近く
- 窓を閉めきった自動車内(とくに夏季) • 風呂場など、湿気の多いところ
- ほこりの多いところ
- 磁石、スピーカーボックス、テレビなど
- の磁気を帯びたものの近く

温度上昇について 本機を長時間お使いになると、本体の温度 が上昇することがありますが、故障ではあ

操作中の動作音について 本機は省電力の動作方式になっています。 そのため、動作中は断続的に動作音がしま すが故障ではありません。

ヘッドホンで聞くときのご注意 付属のヘッドホンは音もれ防止タイプです が、音量を上げすぎると音が外にもれま す。音量を上げすぎて、まわりの人の迷惑 にならないように気をつけましょう。雑音 の多いところでは音量を上げてしまいがち ですが、ヘッドホンで聞くときはいつも呼 びかけられて返事ができるくらいの音量 を、目安にしてください。

表面のお手入れについて

表面が汚れたときは、水やぬるま湯を少し 含ませた柔らかい布で軽くふいたあと、か らぶきをします。シンナー、ベンジン、ア ルコールなどは表面を傷めますので使わな いでください。

について

ワイヤレスコントローラーの防水

本ワイヤレスコントローラーは、水泳など 水中でのご使用はできません。 また、汗や雨などで水分がついた場合は、 すみやかにふき取ってください。

ミニディスクの取り扱いについて ミニディスク自体はカートリッジに収納さ れ、ゴミや指紋を気にせず手軽に取り扱え るようになっています。ただし、カートリ ッジの汚れや反りなどが誤動作の原因にな ることもあります。いつまでも美しい音で 楽しめるように次のことにご注意くださ

ミニディスクに直接触れない シャッターを手で開けないでください。



- 置き場所について
- 直射日光が当たるところなど温度の高い ところや湿度の高いところには置かない でください。また、砂浜など、ディスク に砂が入る可能性のあるところには放置 しないでください
- 定期的にお手入れを
- カートリッジ表面についたほこりやゴミ を、 **乾いた布でふき取ってください**。
- 万一故障した場合は、内部を開けずに、お 買い上げ店またはソニーのサービス窓口に ご相談ください。

故障かな?と思ったら

サービス窓口にご相談になる前にもう一度 チェックしてみてください。

操作を受けつけない

- ・ ディスクが入っていない(ワイヤレスコントロ ーラーに「NO DISC」表示が出る)。
- ⇒ ディスクを入れてください。 • ホールド機能が働いている(本体操作ボタンを 押すとワイヤレスコントローラーに「HOLD」
- 結露(内部に水滴が付着)している。
- 数時間待ってください。
- → 充電式電池を充電するか、乾電池を交換し てください。
- 充電式電池または乾電池が正しく入れられて
- 何も録音されていないディスクが入っている
- 「BLANKDISC」表示が出る)。
- ・ ディスクが損傷している(ワイヤレスコントロ ーラーに「DISC ERR」表示が出る)。
- ときは、他のディスクと取り換えてくださ 使用中、衝撃や過大な静雷気、落雷による雷
- ⇒ 次の手順で操作し直してください。
- **2** 約30秒間そのままにする。
- **3** 電池を入れる
- 「OFF」になっている。
- にしてください。 • 他のワイヤレスコントローラーと混信してい
- → 本体とワイヤレスコントローラーのチャン ネル(CH)を変更してください。 くわしくは、「準備する」の手順4「ワイヤレ ス機能を働かせる。をご覧ください。
- ンネル(CH)になっていない。 ▶「準備する」の手順4「ワイヤレス機能を働か
- ネル(CH)に合わせてください。
- ⇒ 電池を交換してください。
- 金属物の近くにある。 ◆ 金属物から離してください。
- → 近づけてください(約1m以内に)。
- 別売りのリモートコントローラーをつないで 使用している。 → 付属のワイヤレスコントローラーとヘッド
- ホンを使用してください。 いるときは、付属のワイヤレスコントロー

通常の再生ができない リピート再生を指定した。

◆ 再生表示のときにワイヤレスコントローラ -のVOLUME + をくり返し押して、 □ (リピート)表示が消えてから再生を始めて

- 表示が出る)。
- → HOLDスイッチを矢印と逆方向にして、ホ ールド機能を解除してください。
- ⇒ ディスクを取り出して、ふたを開けたまま
- 充電式電池または乾電池が消耗している(ワイ ヤレスコントローラーに「LOW BATT」表示が
- → 充電式電池または乾電池の⊕端子と⊝端子 を正しく入れ直してください。
- (ワイヤレスコントローラーに
- → 録音されたディスクを入れてください。
- → ディスクを入れ直す。それでも表示が出る
- 源電圧の異常などのために強いノイズを受け
- 1 すべての電池を取り出す。
- ワイヤレスコントローラーで操作できない
- 本体のWIRELESS CONTROLスイッチが → WIRELESS CONTROLスイッチを「ON」
- → 他のワイヤレスコントローラーから離して お使いください。
- 本体とワイヤレスコントローラーが同じチャ
- せる」の③~⑥にしたがって、同じチャン
- 雷池が消耗している(ワイヤレスコントローラ ーが時計表示のときに、「秒」表示が点滅す
- 本体とワイヤレスコントローラーが離れすぎ
- 別売のリモートコントローラーをつないで ラーを使って本体を操作することはできま

ディスクの1曲目から再生できない ・ 前回再生したときにディスクの途中で止め

開けて、再生が始まる位置をディスクの最 初に戻してください。

雑音が多い

いている。

充電できない

振動の多い場所に置いている。

再生中に音がとぎれる

→ I◀◀ボタンをくり返し押すか、1度ふたを

⇒ 振動の少ない場所で使ってください。

• ナレーションやイントロなど1曲の録音時間が

極端に短いと、音がとぎれることがありま

• テレビなど強い磁気を帯びたものの近くに置

⇒ テレビなどから離して置いてください。

• 近くで携帯電話など電波を発する機器を使用

→ 携帯電話などから離して使用してくださ

充電器のふたがしっかりと閉まっていない。

ヘッドホンがしっかりと差し込まれていな

♪ Ωジャックにしっかりと差し込んでくださ

→ VOLUME + / - ボタンで音量を調節してく

→ AVLSスイッチを「NORM」にしてくださ

ミニディスクデジタルオーディオシステム

→ しっかりと閉めてください。

ヘッドホンから音が出ない

音量が小さすぎる。

ださい。

主な仕様

ミニディスク

再生読み取り方式

レーザー

回転数

エラー訂正方式

サンプリング周波数

44 1 kHz

コーディング

变調方式

チャンネル数

周波数特性

出力端子

ワウ・フラッター

測定限定値以下

非接触光学式読み取り

(半導体レーザー使用)

= 790 nm

GaAlAsダブルヘテロダイオード

約800 rpm ~ 1800 rpm(CLV)

ソロモンコード(ACIRC)

アドバンスドクロスインターリーブリード

アダプティブトランスフォームアコース

ティックコーディング(ATRAC)

ステレオ2チャンネル

モノラル1チャンネル

20 ~ 20.000 Hz ± 3 dB

最大出力 4 mW+4 mW

負荷インピーダンス 24

ヘッドホン・ステレオミニジャック

電源・その他

杰休・DC 1 5 ∀

暫ください。

ワイヤレスコントローラー

充電器(1)

(防水性能:防滴II型(JIS)(1)

充電式ニッケル水素電池(1)

リチウム電池CR2032(1)

バッテリーキャリングケース(1)

ソニーご相談窓口のご案内(1)

アクティブスピーカー SRS-Z500、

リモートコントローラー RM-M7F1

本機は、ドルビーラボラトリーズライセンシング

本機の仕様および外観は、改良のため予告なく変

更することがありますが、ご了承ください。

Sony on line http://www.world.sony.com/ 「Sony online」は、インターネット上のソニーのエレクトロニクスとエンターテインメントのホームページです。

___ この説明書は再生紙を使用しています。

コーポレーションの米国及び外国特許に基づく

リチウム電池CR2032(ワイヤレスコント

SRS-7750, SRS-71000

MDラベルプリンター M7P-1

乾電池ケース(1)

取扱説明書(1)

安全のために(1)

別売りアクセサリー

ローラー用)

許諾製品です。

保証書(1)

キャリングポーチ(1)

搬送周波数

外形寸法

付属品

雷源

充電式電池(付属:NH-14WM) 単3形アルカリ乾雷池1本(別売り) ワイヤレスコントローラー: DC 3.0 V リチウム電池1個(付属: CR2032)

As you read, refer to the illustrations in the Japanese text 電池持続時間(EIAJ)

Welcome to the world of the MiniDisc! Below 充電式電池・乾電池およびリチウム電池の you will find descriptions of some of the 持続時間については、「電源について」をご pabilities and features that you will

· Wireless control by wristwatch-styl 239.54 MHz

- The wireless controller allows you to 約87 x 22 x 76 mm control basic player functions, display track (幅/高さ/奥行き、最大突起部含まず) titles, and set playback parameters on a backlit, 9-character LCD
- 約149 g(再生専用ミニディスク、充電式 Simple "One-Touch Eject" function for easy MiniDisc handling 電池NH-14WMを含む ` A single press of a button on the side of the player causes the player lid to open and the ヘッドホン(1) MiniDisc to eject.
 - Versatile wristwatch functions The wireless controller also acts as a wristwatch with calendar, stopwatch, and alarm functions.

discover on your new MiniDisc player

- Low power-consumption design for longer battery life. • Forty-second memory for correction of
- reading errors caused by shocks.

► Getting started

Getting started A

Before you can use your player, you must first insert the supplied rechargeable battery into the player (or attach a dry battery (not supplied)), and insert the supplied button battery into the wireless controller (see "Power Sources" for more details).

1 Charge the supplied NH-14WM rechargeable battery with the supplied battery charger. After about 1.5 hours, charging ends and

the lamp on the charger turns off. (To get

maximum performance from the battery

continue charging it for another hour

after the lamp turns off.) A fully charged battery should provide about 15 hours of playback **2** Open the lid of the rechargeable battery

compartment and insert the charged

- 3 Use a coin to open the lid of battery compartment on the bottom of the wireless controller and insert the supplied button battery with the plus side facing up. Replace the lid and screw it in until it is
- 4 Use the wireless controller The wireless controller can be used right out of the box. No need to set it up. (The CH switch is factory-set to A(ch).) (1) Make sure that the WIRELESS
- Normally, there is no need to turn this switch OFF, except when using the player on airplanes (2) Make sure that the CH switch on the player is set to A.

. If you experience interference from

through 6 to switch your controller

other wireless controllers, do steps (3)

CONTROL switch on the player is set

- o another channel (B) 3 Use the tip of a ballpoint pen or mother sharp-tipped implement to se the CH switch on the player to B.
- (4) Press MODE on the wireless ontroller repeatedly to display the mode indication. Press down MODE for about 3 seconds while the mode indication is on.
- ⑤ Press VOLUME +/- on the wireless ontroller until "B ch" is displayed. 6 Push the control on the wireless controller towards the right to

complete the changing of the channel.

►MD playing

Playing an MD! B

The player automatically switches to nonaural or stereo mode according to the sound source.

1 Inserting an MD.

- ① Press OPEN. (2) Insert the MD with the label side facing up. Then close the lid by pressing down on it.
- 2 Playing the MD
- ① Connect the supplied headphones to the () jack on the player. Be sure the headphones plug is firmly inserted into the player
- ② Press (or push the control on the wireless controller towards the The OPERATE lamp on the player lights up and the player starts to play the first track. A short beep sounds in the
- wireless controller for this ster 3 Press VOLUME +/- to adjust the The volume is displayed on the LCD whenever you operate the wireless

headphones when you use the

To stop playback, press ■ (or ■ on

The OPERATE lamp on the player goes off. A long beep sounds in the headphones when you use the wireless controller for this step. About the wireless controller

the player and the wireless controller The wireless controller sends control signals to the player.

The following radio transmissions occur between

 The player sends information to the wireless The communication lamp on the player turns on whenever the player sends information to the wireless controller or receives a signal from the vireless controller. Two kinds of information are displayed on the LCD on the wireless controller The control indication when the wireless

volume adjustment operation.

• The mode indication during repeat play or the display of a track title. Due to its use of radio waves, keep the following points in mind when using the wireless

controller is used to do a playback, cueing, or

- Do not use the wireless controller on an airplane as the emitted signals may interfer with the airplane's communication system.

 Make sure the WIRELESS CONTROL switch on the player is turned OFF during the fligh (Do not use the player in an airplane during take-off or landing (or at any other time whe
- the use of the electronic devices is restricted). Operate the wireless controller within 1 mete of the player. Under the following conditions, radio transmission may be poor, and the effective communication distance between the wireless
- controller and the player may be shorter than When the headphone cord is wound round When the player is near a metallic object or
- When there are items blocking the radio issions between the player and the wireless controller. - When the player is near a computer or other source of electromagnetic noise.

when the MD in the player has a metallic

When the player is near a source of strong radio waves, such as TV or radio When the player is inside a car or train - When the player is near people using

radios or wireless walkmans.

only with this player.

If the communication between the player and wireless controller is poor, or if the player does position or orientation of the player or wireless The supplied wireless controller can be use

Other disc operations

Cue to the

Cue to the

Cue to the

beginning of

Go forward

MD

the next track

beginning of

track

in the headphones

Press ► twice, or push

the control on the wireless

controller twice towards

the left (three short beeps

Press > once. or

push the control on the

wireless controller onc

towards the right (two

short beeps sound in

the wireless controller

Hold down ▶► . or

push and hold the contro

on the wireless controller

Press ■, (or press ■ on

the wireless controller

towards the left.

towards the right.

sure the player is not locked. See "To

sound twice in

headphones)

headphones)

Go backwards Hold down ◄ . or push

while playing and hold the control on

* If you open the lid, the next playback

If communication between the

The antenna icon on the right side of the

display disappears whenever the communication link between the wireless

• Change the position or orientation of the

The wireless control function may not have

wireless controller to restore the link.

been set correctly. See step 4 "Use the

wireless controller" in "Getting started.

Playing tracks repeatedly C

1 Press MODE on the wireless controller

indication. When the player receives a

signal from the wireless controller, the

node indication changes to the play

controller while the play indication is on

mode indication changes as follows

Each time you press VOLUME +, the play

repeatedly to display the mode

2 Press VOLUME + on the wireless

indication.

(None) (Normal play)

SHUF
(Shuffle repeat)

random order.

(All repeat)

All the tracks are played once.

All the tracks are played repeatedly

All the tracks are played repeatedly in

controller and the player is broken.

If this happens, do the following:

wireless controller and the player is

If playback does not start

Lock the controls.

broken

To display the track name and Do the following (Beep playing time during playback D 1 Press MODE on the wireless controller Press | once, or push repeatedly during playback until the the control on the wireless mode indication appears. When the controller once towards player receives a signal from the wireless the left (three short beeps controller, the mode indication changes to sound in headphones) the play indication.

> 2 Press VOLUME - on the wireless controller while the play indication is on. Each time you press VOLUME -, the display changes in the following sequence: the elapsed playing time of the current track and the track number, the track name and the track number, and the disc name and the number of tracks on the MD.

Disc and track names appear only for MDs on

(DIGITAL MEGABASS)

Using other functions

To Lock the controls **E** Slide HOLD in the direction of the - to lock the controls of the player. To emphasize bass

Set DIGITAL MEGABASS to 1 (weak) o To cancel the effect, set DIGITAL MEGABASS

To safeguard your hearing (AVLS) G Set AVLS (Automatic Volume Limiter

This sets a moderate volume level that cannot

If the emphasized bass causes the sound to

be exceeded even if you try to raise the

volume beyond it. **►**Clock Functions

System) to LIMIT.

- Setting the clock and calendar 1 Press MODE on the wireless controller
- 2 While the clock is displayed, press down MODE on the wireless controller for about 3 seconds. The calendar setting display will appea

repeatedly until the clock appears.

3 Press VOLUME +/- on the wireless ontroller repeatedly to set the year

digits of the year.)

will appear.

- 4 Push the control on the wireless controller towards the right to complete the setting of the year. The month digits will flash Repeat steps 3 and 4 to set the month and When you push the control on the wireless controller towards the right after setting the day, the clock setting display
- 5 Select a 12-hour or 24-hour clock. Press VOLUME +/- to select the 12-hour or 24-hour clock, and then push the control towards the right to complete the

To change a previously set item, push the

control on the wireless controller towards

After setting the minute, push the control right. The second digits will change to "00" and the clock will begin operating from the specified time

6 Repeat steps 3 and 4 to set the hour and

Press MODE on the wireless controller

To quit the time and calendar setting

Using the stopwatch function

The split-second function allows you to freeze the count as many times as you want, even a the stopwatch continues to operate.

- 1 Press MODE on the wireless controller repeatedly to display the stopwatch
- **2** Press VOLUME on the wireless The stopwatch on the wireless controller Press VOLUME - again to stop the

To reset the stopwatch After stopping the stopwatch, press VOLUME +

stopwatch.

To use the split-second function After starting the stopwatch, press VOLUME + on the wireless controller at any point. The tim indication freezes ("SP" appears), showing the elapsed time up to that point.

Press VOLUME + again to unfreeze the stopwatch ("SW" appears)

Using the alarm function J Make sure to set the clock before setting the

1 Press MODE on the wireless controller

- repeatedly to display the alarm **2** Press VOLUME – on the wireless controller repeatedly to select "AL1.
- **3** Press down MODE on the wireless ontroller for about 3 seconds The hour digits will flash.

4 Press VOLUME +/- on the wireless

controller repeatedly to set the hour

"AL2," or "AL3."

- 5 Push the control on the wireless controller towards the right to complete the setting of the hour. The minute digits will flash To reset the hour, press MODE on the wireless controller to guit the alarm
- **6** Repeat steps 4 and 5 to set the minute After entering the alarm time, push the control on the wireless controller towards the right to activate the alarm.

setting, and then do steps 3 to 6 again

- and the year digits will begin to flash. To quit the alarm setting (The year digits indicate the last two Press MODE on the wireless controlle
 - To deactivate an alarm While the alarm indication is displayed, select the alarm time ("AL1," "AL2," or "AL3") to be deactivated, and then press VOLUME + on the (the "(•)" indication disappears

(the "(•)"indication appears)

To activate the alarm again While the alarm indication is displayed, select the alarm time ("AL1," "AL2," or "AL3") to be activated, and then press VOLUME + on the wireless controller (the "(•)" indication appears)

To stop an alarm

If the clock is not set, you cannot set the alarm

Turning on the backlight K

Press the control or any other button on the

wireless controller to stop an alarm.

Press LIGHT on the wireless controller to turn on the backlight. After you release the LIGHT button, the backlight will stay on for about 5 seconds.

▶Power Sources

Using on a battery <a>I

The player

nsert a new LR6 (size-AA) alkaline battery into the supplied battery case, making sure the battery terminals are properly oriented Then attach the battery case to the player. A new battery should provide about 21 hours of playback.

The combined use of a full charged batters and a new LR6 alkaline battery should resul in about 40 hours of playback. The wireless controlle The service life of the battery is about 3

> When to recharge or replace the batteries The player:

en the battery is nearly exhaust "LOW BATT" will flash in the LCD on the vireless controller whenever a signal transmission occurs between the wireless ontroller and the player. A little while later, the power to the player will stop completely. The wireless controller:
The battery in the wireless controller should be replaced when the second digits in the clock begin to flash. But even if the second digits do not flash the battery should be replaced when the effective

communication distance between the wireless

when communication stops altogether

troller and the player grows very short or